

CodeMyCar

www.codemycar.com

codemycar@gmail.com

www.youtube.com/codemycar

www.facebook.com/codemycar

RR01/02/04/05/06

Coding/Tuning/Programming/Retrofit Options

A) PERFORMANCE/DRIVABILITY

(Additional Charges Apply)

- 1) ECU Tune (Phantom, Drophead, Ghost, Wraith, Dawn)
- 2) Software/Firmware Updates (DME, EGS, DSC & All Other Modules)
- 3) Throttle Controller (21 Driving Modes) – Will Help Increase Fuel Efficiency OR Eliminate Throttle Lag

B) CODING

- 1) DVD In Motion
- 2) Enable Video Playback Via USB Port. Video Playback Possible From USB Flash Drive/SSD Harddrive
- 3) Allow The Ability To Add New Devices (Phone, iPod) To The System While Driving
- 4) Screen Mirroring & Miracast (Android Devices Only) – 2017+ Models w/Navigation Only
- 5) Enable The Ability To Use Office Functionality While Driving (Only Available With BMW Office)
- 6) Turn On Zoom Feature For Rear View Camera
- 7) Disable Legal Disclaimers (Startup, Camera, Etc.)
- 8) Enable Tire Pressure & Temperature Readings In iDrive
- 9) Transfer Phone's Ringtone To Vehicle (iPhones Only)
- 10) Change US Nav Voice To UK Nav Voice
- 11) Enable ///M Logo On Startup, Instead Of Normal Logo
- 12) Change Rolls Royce Sounds/Gongs To BMW, Mini or BMWi
- 13) Enable The Ability To Read Full Texts/Emails (As Opposed To First 3 Lines) – Requires BMW Office
- 14) Disable Seat Belt Chimes
- 15) Close Windows & Sunroof With KeyFob
- 16) Fold/Unfold Side Mirrors With KeyFob & Comfort Access
- 17) Fold Side Mirrors As Soon As The Vehicle Is Locked
- 18) Disable Window Safety (Allows One Touch Up Window Operation W/Door Open)
- 19) Start Car Without Braking
- 20) Unlock Doors When Car Is Turned Off
- 21) Radio/Nav Turns Off When Door Is Opened (After Pressing Stop Button Once)
- 22) Disable Interior Alarm Motion Sensor (Beneficial If You Often Travel With Your Pet/Pets)
- 23) Close Trunk From Key & Interior Button
- 24) Disable DRL (Light Beam) Dimming (When Low Beams Are Turned On)
- 25) Enable Taillights As DRLs, In Addition To Front DRLs/Light Beams
- 26) Enable Fog Lights As Welcome Lights
- 27) Run High Beams & Fog Lights Simultaneously
- 28) Disable Fogs/Cornering Lights From Turning On When You Are Turning Left & Right
- 29) Enable Brake Force Braking (Flashing Taillights Activated With Heavy Braking)
- 30) Remove Light Errors (Caused By Aftermarket LED Lights, etc.)
- 31) Disable Auto-Dimming Side Mirrors
- 32) Enable Auto High Beam Assist - Requires Driver Assistance Package w/Lane Departure
- 33) Enable Lane Departure in HUD (Requires Lane Departure Warning & HUD Packages)
- 34) Digital Speedometer
- 35) Lower Distance At Which Fuel Warning Is Activated (2014+ Models Only)
- 36) Blinkers In HUD
- 37) Default Active Cruise Vehicle Distance From 4 Bars To 1, 2 Or 3 Bars (Requires Active Cruise Ctrl ACC)

- 38) Disable Top Speed Restriction For Cameras (Can Be Used While Driving)
- 39) Always Remember Seat Heating & Cooling Memory Upon Vehicle Start
- 40) Adjust The Temperatures For Seat Cooling To Enable Cooler Ventilation Settings (Vehicle Must Have Seat Cooling Already, In Order To Alter Settings)
- 41) Disable AC/Climate From Automatically Turning On When Car Is Started (Set Climate Settings To Last Memory)
- 42) Pressing 'Auto' On The Climate Control Does Not Activate AC
- 43) Enable Blind Spot Detection To Be Active From 12mph Instead Of 30mph
- 44) Disable Headlight Washers

C) UPDATES (Additional Charges Apply)

- 1) 2020.1 NBT Navigation Map Update
- 2) 2020 CIC Navigation Map Update

D) SERVICES (Additional Charges Apply)

- 1) Radar Detector Hardwiring
- 2) K40 Radar/Laser Systems
- 3) Escort Radar/Laser Systems